

ChiaoGoo TWIST & SPIN Interchangeables - Knitter's Guide

Circular Length Guide

Item Description	Join Code	Needle Size (US)															Cable Length						Accessories												
		2	2.5	3	4	5	6	7	8	9	10	10.5	10.75	10.875	11	13	15	8"	14"	22"	30"	37"	50"	Cable Connectors	End Stoppers	Stitch Markers	Needle Gauge	Keys	Needle Case						
		Needle Size (mm)															Cable Length (cm)																		
		2.75	3	3.25	3.5	3.75	4	4.5	5	5.5	6	6.5	7	7.5	8	9	10	20	35	55	75	93	125												
4" (10 cm) Sets																																			
Small	[S]	◆		◆	◆	◆	◆	◆	◆									◆										1 [S]	2 [S]	2x6	◆	2	◆		
Complete	[S] & [L]	◆		◆	◆	◆	◆	◆	◆	◆	◆	◆			◆	◆	◆	◆										1 ea [S & L]	2 ea [S & L]	4x6	◆	2	◆		
5" (13 cm) Sets																																			
Small	[S]	◆		◆	◆	◆	◆	◆	◆										◆	◆	◆							1 [S]	2 [S]	2x6	◆	2	◆		
Large	[L]									◆	◆	◆			◆	◆	◆		◆	◆	◆							1 [L]	2 [L]	2x6	◆	2	◆		
Complete	[S] & [L]	◆		◆	◆	◆	◆	◆	◆	◆	◆	◆			◆	◆	◆		◆	◆	◆							1 ea [S & L]	2 ea [S & L]	4x6	◆	2	◆		
Parts and Pieces Available for Separate Purchase																																			
Tips 4" (10 cm) - Small	[S]	◆	◆	◆	◆	◆	◆	◆	◆																										
Tips 4" (10 cm) - Large	[L]									◆	◆	◆	◆	◆	◆	◆	◆																		
Tips 5" (13 cm) - Small	[S]	◆	◆	◆	◆	◆	◆	◆	◆																										
Tips 5" (13 cm) - Large	[L]									◆	◆	◆	◆	◆	◆	◆	◆																		
8"/20 cm Cable - Small	[S] 8"/20																	◆															1		
14"/35 cm Cable - Small	[S] 14"/35																		◆														1		
22"/55 cm Cable - Small	[S] 22"/55																			◆													1		
30"/75 cm Cable - Small	[S] 30"/75																				◆												1		
37"/93 cm Cable - Small	[S] 37"/93																					◆											1		
50"/125 cm Cable - Small	[S] 50"/125																																1		
8"/20 cm Cable - Large	[L] 8"/20																	◆															1		
14"/35 cm Cable - Large	[L] 14"/35																		◆														1		
22"/55 cm Cable - Large	[L] 22"/55																				◆												1		
30"/75 cm Cable - Large	[L] 30"/75																					◆											1		
37"/93 cm Cable - Large	[L] 37"/93																						◆										1		
50"/125 cm Cable - Large	[L] 50"/125																																1		
Cable Connectors - Small	[S]																											2 [S]							
Cable Connectors - Large	[L]																											2 [L]							
End Stoppers - Small	[S]																												2 [S]						
End Stoppers - Large	[L]																												2 [L]						
Stitch Markers																														4x10					
Needle Gauge - 5" (13 cm)																															1				
Keys																																4			
Interchangeable Needle Case																																		White	

Cable (Inch)	Tip Length	
	4 inch	5 inch
8	16"	X
14	22"	24"
22	30"	32"
30	38"	40"
37	45"	47"
50	58"	60"
8 + 14	30"	32"
8 + 22	38"	40"
14 + 22	44"	46"
8 + 30	46"	48"
14 + 30	52"	54"

Cable (cm)	Tip Length	
	10 cm	13 cm
20	41 cm	X
35	56 cm	61 cm
55	76 cm	81 cm
75	97 cm	102 cm
93	113 cm	119 cm
125	146 cm	151 cm
20 + 35	76 cm	81 cm
20 + 55	97 cm	102 cm
35 + 55	112 cm	117 cm
20 + 75	117 cm	122 cm
35 + 75	132 cm	137 cm

TWIST – Stainless Steel; SPIN – Bamboo; [S] = Small join compatible with US2 (2.75mm) - US8 (5mm) tips; [L] = Large join compatible with US9 (5.5mm) - US15 (10mm) tips; Indicated tip length includes metal cable join when connected to cable; 8"/20cm cable should only be used with 4"/10cm tips or in conjunction with other cables; TWIST & SPIN tips, cables and accessories are all switchable!

*Lengths are approximate.

TWIST/SPIN Parts & Pieces Working Instructions



[S] & [L] Coding – Most TWIST & SPIN parts and pieces are coded [S] for small screw size and [L] for large screw size. Parts coded [S] are compatible with other [S] coded parts and US2 (2.75mm) – US8 (5mm) tips. Parts coded [L] are compatible with other [L] coded parts and US9 (5.5mm) – US15 (10mm) tips.



End Stoppers – Black or white, rectangular-shaped resin pieces screw into your cable ends to hold a current project while using the tips for another project. White [S] end stoppers fit onto all [S] coded cables. Black [L] end stoppers fit onto all [L] coded cables.



T-Shaped Keys – When screwing in your tips, insert this key into the lifeline hole found on each metal joint at the ends of your TWIST & SPIN cables. Simply use the key as a handle to help you grasp and tighten the screw connection. It is highly recommended to use the key EVERY time you attach your tips to a cable. For an even better connection, try using a rubber band/gripper pad wrapped around the tip with the key. You will need the key to loosen the connection when removing the tips from the cable.



Lifeline Hole – Drilled hole on each metal joint at the ends of your TWIST & SPIN cables. Thread thin yarn or floss into the hole. While you knit your row this thread will knit in with your stitches providing a safety net in case you need to rip out rows - you now have a point to go back to. It is also used with the T-shaped key to assist with tightening your tip/cable connection as described above.



Cable Connectors – Tiny "tic tac" sized pieces of metal that allow you to join two or more cables together to make a longer one. It is highly recommended to use the T-shaped keys when connecting cables together. Small [S] connectors fit onto all [S] coded cables. Large [L] connectors fit onto all [L] coded cables.

**All TWIST & SPIN tips, cables,
and accessories are switchable!**